

---

# NI-7932

---

2022-07-06




# Contents

GSG Purpose. . . . .	3
FlexRIO Documentation. . . . .	3
Safety Guidelines. . . . .	4
Electromagnetic Compatibility Guidelines. . . . .	5
Verifying the System Requirements. . . . .	6
What You Need to Get Started. . . . .	6
Unpacking the Kit. . . . .	7
Preparing the Environment. . . . .	7
Wiring Power to the NI-7932R. . . . .	8
Powering on the NI-7932R. . . . .	9
STATUS LED. . . . .	9
Connecting the NI-7932R to the Host Computer. . . . .	10
Installing the FlexRIO Adapter Module. . . . .	11
Configuring the System in Measurement & Automation Explorer (MAX). . . . .	11
Setting a System Password. . . . .	12
Installing Software on the NI-7932R. . . . .	13
Adding the NI-7932R to a LabVIEW Project. . . . .	14
Adding a FlexRIO Adapter Module to the Target. . . . .	14
Programming Options. . . . .	14
Programming with LabVIEW. . . . .	15
Text-based Programming. . . . .	15
Removing the Adapter Module. . . . .	15
Troubleshooting the NI-7932R. . . . .	15
Why Can't the NI-7932R Communicate with the Network?. . . . .	16
Why Doesn't the Device Appear in MAX?. . . . .	16
Appendix: Front Panel. . . . .	17
NI-7932R Front Panel. . . . .	17
Worldwide Support and Services. . . . .	19
Where to Go Next. . . . .	20

## GSG Purpose

This document describes how to begin using the NI-7932R.

Figure 1. NI-7932R



### Related information

- <http://www.ni.com/manuals>

## FlexRIO Documentation

Document	Location	Description
Getting started guide for your controller for FlexRIO	Available from the Start menu and at <a href="http://ni.com/manuals">ni.com/manuals</a> .	Contains installation instructions for your FlexRIO system.
Specifications document for your controller for FlexRIO	Available from the Start menu and at <a href="http://ni.com/manuals">ni.com/manuals</a> .	Contains specifications for your controller for FlexRIO.
Getting started guide for your adapter module	Available from the Start menu and at <a href="http://ni.com/manuals">ni.com/manuals</a> .	Contains signal information, examples, and CLIP details for your adapter module.
Specifications document for your adapter module	Available from the Start menu and at <a href="http://ni.com/manuals">ni.com/manuals</a> .	Contains specifications for your adapter module.

Document	Location	Description
<b>LabVIEW FPGA Module Help</b>	Embedded in <b>LabVIEW Help</b> and at <a href="http://ni.com/manuals">ni.com/manuals</a> .	Contains information about the basic functionality of the LabVIEW FPGA Module.
<b>Real-Time Module Help</b>	Embedded in <b>LabVIEW Help</b> and at <a href="http://ni.com/manuals">ni.com/manuals</a> .	Contains information about real-time programming concepts, step-by-step instructions for using LabVIEW with the Real-Time Module, reference information about Real-Time Module VIs and functions, and information about LabVIEW features on real-time operating systems.
<b>FlexRIO Help</b>	Available from the Start menu and at <a href="http://ni.com/manuals">ni.com/manuals</a> .	Contains information about the FPGA module front panel connectors and I/O, controller for FlexRIO front panel connectors and I/O, programming instructions, and adapter module component-level IP (CLIP).
<b>FlexRIO Adapter Module Development Kit User Manual</b>	Available from the Start menu at Start » All Programs » National Instruments » NI FlexRIO » NI FlexRIO Adapter Module Development Kit » Documentation.	Contains information about how to create custom adapter modules for use with FlexRIO FPGA modules.
LabVIEW Examples	Available in NI Example Finder. In LabVIEW, click Help » Find Examples » Hardware Input and Output » FlexRIO.	Contains examples of how to run FPGA VIs and Host VIs on your device.
IPNet	Located at <a href="http://ni.com/ipnet">ni.com/ipnet</a> .	Contains LabVIEW FPGA functions and intellectual property to share.
FlexRIO product page	Located at <a href="http://ni.com/flexrio">ni.com/flexrio</a> .	Contains product information and data sheets for FlexRIO devices.

Table 1. FlexRIO Documentation Locations and Descriptions

## Safety Guidelines



**Caution** You can impair the protection provided by the NI-7932R if you use it in a manner not described in this document.

## Electromagnetic Compatibility Guidelines

This product was tested and complies with the regulatory requirements and limits for electromagnetic compatibility (EMC) stated in the product specifications. These requirements and limits provide reasonable protection against harmful interference when the product is operated in the intended operational electromagnetic environment.

This product is intended for use in industrial locations. However, harmful interference may occur in some installations, when the product is connected to a peripheral device or test object, or if the product is used in residential or commercial areas. To minimize interference with radio and television reception and prevent unacceptable performance degradation, install and use this product in strict accordance with the instructions in the product documentation.

Furthermore, any changes or modifications to the product not expressly approved by National Instruments could void your authority to operate it under your local regulatory rules.



**Caution** To ensure the specified EMC performance, operate this product only with shielded cables and accessories. The DC power input cables and optical SFP+ cables may be unshielded.



**Caution** To ensure the specified EMC performance, you must use an isolated cable with the SFP+ ports.



**Caution** To ensure the specified EMC performance, the length of any cable connected to the TRIG ports and REF CLK ports must be no longer than 3 m (10 ft). The length of copper cables connected to the SFP+ ports must be no longer than 3 m (10 ft). The length of cables connected to the

USB device ports or host ports must be no longer than 30 m (100 ft). The lengths of Ethernet cables and optical SFP+ cables are not limited.



**Caution** The USB device port is intended only for use in device configuration, application deployment, debug, and maintenance.

## Verifying the System Requirements

To use the NI-7932R, your system must meet certain requirements. For more information about minimum system requirements, recommended system, and supported application development environments (ADEs), refer to the readme, which is available on the software media or online at [ni.com/updates](https://ni.com/updates).

## What You Need to Get Started

- The NI-7932R shipping kit, which includes the following components:
  - The NI-7932R device
  - FlexRIO Support DVD



**Note** FlexRIO Support 15.1 is the earliest supported driver for the NI-7932R.

- **NI-7932R Getting Started Guide** (this document)
- Power screw terminal connector plug
- A to Mini-B device port USB cable
- A host computer running Windows, with NI software installed in the following order:



**Note** Visit [ni.com/info](https://ni.com/info) and enter the Info Code rdsoftwareversion to determine which software versions you need to use the NI-7932R and supported FlexRIO adapter modules.

- LabVIEW

- LabVIEW Real-Time
- LabVIEW FPGA
- FlexRIO Support<sup>[1]</sup>
- A DC power supply as described in the **NI-7932R Specifications**
- A FlexRIO adapter module or custom adapter module (optional)
- A number 2 Phillips screwdriver
- A number 1 Phillips screwdriver
- A small flat-blade screwdriver
- Straight through shielded Ethernet cable (if connecting to a network) or crossover shielded Ethernet cable (if connecting directly to a PC)

<sup>1</sup> LabVIEW 2015, FlexRIO Support 2015, LabVIEW Real-Time 2015, and LabVIEW FPGA 2015 are the earliest versions of software that support the NI-7932R.

## Unpacking the Kit



**Caution** To prevent electrostatic discharge (ESD) from damaging the device, ground yourself using a grounding strap or by holding a grounded object, such as your computer chassis.

1. Touch the antistatic package to a metal part of the computer chassis.
2. Remove the device from the package and inspect the device for loose components or any other sign of damage.



**Caution** Never touch the exposed pins of connectors.



**Note** Do not install a device if it appears damaged in any way.

3. Unpack any other items and documentation from the kit.

Store the device in the antistatic package when the device is not in use.

## Preparing the Environment

Ensure that the environment you are using the NI-7932R in meets the following specifications.

Operating temperature (IEC 60068-2-1, IEC 60068-2-2)	0 °C to 55 °C
Operating humidity (IEC 60068-2-56)	10% to 90% RH, noncondensing
Pollution Degree	2
Maximum altitude	2,000 m at 25 °C ambient temperature

Indoor use only.



**Note** Refer to the **NI-7932R Specifications** at [ni.com/manuals](https://ni.com/manuals) for complete specifications.



**Caution** Clean the hardware with a soft, nonmetallic brush. Make sure that the hardware is completely dry and free from contaminants before returning it to service.

## Wiring Power to the NI-7932R

The NI-7932R requires a 9 V to 30 V external power supply that meets the specifications in the **NI-7932R Specifications**. The NI-7932R filters and regulates the supplied power and provides power for the I/O modules.



**Note** You can latch the power plug to the NI-7932R using two screws tightened to 0.20 to 0.25 N · m (1.8 to 2.2 lb · in.) of torque.

The maximum wire gage accepted by the power connector plug is 16 AWG. You must use a stripped wire length of 10 mm (.394 in).

When the POWER LED on the front panel is lit green, the device is powered.


The NI-7932R has reverse-voltage protection.

Complete the following steps to connect a power supply to the NI-7932R.

1. Ensure the power source is turned off.



2. Connect a positive wire to the positive terminal of the power connector plug, and connect a negative wire to the negative terminal of the power connector plug.



1. Positive terminal
  2. Negative terminal
  3. No connect
3. Install the power connector on the front panel of the NI-7932R.
  4. Turn on the external power source(s).

## Powering on the NI-7932R

When you apply power for the first time to the NI-7932R, the controller boots into safe mode. The POWER LED illuminates, the STATUS LED illuminates briefly, and then the STATUS LED blinks twice every few seconds.

After you install software on the controller, subsequent reboots will boot the controller into the NI Linux Real-Time operating system.

You can optionally configure the NI-7932R to launch an embedded stand-alone LabVIEW Real-Time application each time you boot the controller.

## STATUS LED

The STATUS LED is off during normal operation. The NI-7932R indicates specific error conditions by flashing the STATUS LED a certain number of times every few seconds, as shown in the following table.

LED State	Indication
2 flashes every few seconds	There is no software installed, which is the out-of-box state, or the controller has detected an error in its software.  An error can occur when an attempt to upgrade the software is interrupted. Refer to the <b>MAX Help</b> for information about reinstalling software on the controller.

LED State	Indication
3 flashes every few seconds	The controller is in safe mode. Refer to the <b>MAX Help</b> for information about safe mode.
4 flashes every few seconds	The software has crashed twice without rebooting or cycling power between crashes. This usually occurs when the controller runs out of memory. Review your Real-Time VI and check the memory usage. Modify the VI as necessary to solve the memory usage issue.
Continuously flashing	The controller has not booted into NI Linux Real-Time. The controller either booted into an unsupported operating system, was interrupted during the boot process, or detected an unrecoverable software error.
Solid	The controller is booting up.
Continuously flashing	This indicates a hardware error. An internal power supply has failed. Check front-panel I/O and adapter module connections for shorts. Remove any shorts and power cycle the controller. If the problem persists, contact National Instruments.
Off	Normal operation.

## Connecting the NI-7932R to the Host Computer

Complete the following steps to connect the NI-7932R to the host computer using the USB device port.

1. Power on the host computer.
2. Connect the NI-7932R to the host computer using the USB A-to-B cable.



**Note** Alternatively, you can use the RJ-45 Ethernet port to connect the NI-7932R to the host computer.

The device driver software automatically detects the NI-7932R. If the device driver software does not detect the NI-7932R, verify that you installed the appropriate NI software in the correct order on the host computer.



**Tip** You can also use the Ethernet port to connect directly to the host computer or network. Refer to the user manual on [ni.com/manuals](http://ni.com/manuals) for more information about Ethernet connections.

#### Related concepts

- [Troubleshooting the NI-7932R](#)


## Installing the FlexRIO Adapter Module

Skip this section if you are not using a FlexRIO adapter module.

1. Gently insert the guide pins and the high-density card edge of the FlexRIO adapter module into the corresponding connectors of the NI-7932R. The connection may be tight, but do not force the adapter module into place.
2. Tighten the captive screws on the FlexRIO adapter module to secure it to the NI-7932R.

The following figure shows the NI-7932R with the FlexRIO adapter module connected.

Figure 1. NI-7932R with FlexRIO Adapter Module



Refer to the getting started guide for your adapter module for more information about your adapter module, including programming information.

## Configuring the System in Measurement & Automation Explorer (MAX)

After connecting the NI-7932R to the host computer, complete the following steps to configure the system for the first time in MAX.

1. Launch MAX on the host computer.
2. Expand Remote Systems in the MAX configuration tree and select the system. MAX lists the system as the model name followed by the serial number, such as NI-7932R-030521C9.

### Related reference

- [Why Doesn't the Device Appear in MAX?](#)

## Setting a System Password

Complete the following steps to set a system password.



**Note** Setting a system password is optional.



**Note** The default username for the NI-7932R is admin. There is no default password for the NI-7932R, so you must leave the password field blank when logging in until you set a system password.

1. Right-click your system and select Web Configuration. The NI Web-Based Configuration and Monitoring utility opens in your default browser and is where you set the password. If you have not installed Microsoft Silverlight, NI Web-based Configuration & Monitoring prompts you to do so.
2. Enter a unique name for your system in the Hostname field.
3. Click the Security Configuration icon.
4. Click Login.
5. In the Login dialog box, enter the username admin and leave the password field blank.

6. Click OK.
7. Click Change Password.
8. Enter and re-enter a new password.
9. Click OK.
10. Click Save.
11. Click OK to confirm you are changing the password.



**Caution** NI cannot recover lost system passwords. If you forget the password, you must contact NI and reformat the controller.

## Installing Software on the NI-7932R

1. Open Measurement & Automation Explorer (MAX).
2. Expand the system under Remote Systems by clicking the arrow beside it.
3. Select Software.
4. Click Add/Remove Software at the top of the Software tab to launch the LabVIEW Real-Time Software Wizard.



**Note** A login window appears if you set a system password.

5. Select a recommended software set to install.
6. Click Next.
7. The recommended software set is preselected from the list of software add-ons. Check any additional software add-ons you want. The System State Publisher, for example, makes monitoring system performance simple.



**Note** You can use the LabVIEW Real-Time Software Wizard to install more software add-ons later. The FlexRIO 15.0 Recommended Software Set is enough to get started.

8. Click Next.
9. Review the summary of software to install. Click Next to begin the update.

10. Wait for the installation to finish, and then click Finish.

## Adding the NI-7932R to a LabVIEW Project

1. Launch LabVIEW. The LabVIEW Getting Started window appears.
2. Click Create Project or open an existing project.
3. Right-click the project root in the Project Explorer window and select New » Targets and Devices from the shortcut menu to display the Add Targets and Devices dialog box.
  1. If the hardware is connected to the host, select Existing target or device. Select the NI-7932R under Real-Time FlexRIO and click OK.
  2. If the hardware is not connected to the host, select New target or device. Select the NI-7932R under Real-Time FlexRIO and click OK.
4. Right-click the target and select New » FPGA Target. The FPGA target appears in the project under the Real-Time target.

## Adding a FlexRIO Adapter Module to the Target

Skip this section if you are not using an adapter module.

1. Expand the FPGA target by clicking the + button, then right-click IO Module and select Properties.
2. Select the General category and check the Enable IO Module box.
3. Select your I/O module from the IO Modules list, and select the CLIP you want to use from the Component Level IP box.
4. Click OK.

## Programming Options

Refer to the following table for information about how to program the NI-7932R.

Component	Programming Option(s)
Real-Time controller	LabVIEW Real-Time or C/C++ Development Tools for NI Linux Real-Time, Eclipse Edition.

Component	Programming Option(s)
FPGA	LabVIEW FPGA

### Related information

- <http://www.ni.com/manuals/>
- <http://www.ni.com/tutorial/14625/en/>

## Programming with LabVIEW

The Controller for FlexRIO examples provide a starting point for programming with LabVIEW. To access these examples, open LabVIEW and select Help » Find Examples » Hardware Input and Output » Controller for FlexRIO.

For more detailed instructions about programming the NI-7932R with LabVIEW, refer to the **NI-7931R/7932R/7935R User Manual**.

## Text-based Programming

You can target the NI-7932R Linux Real-Time operating system from text-based development environments such as C and C++.

## Removing the Adapter Module

Complete the following steps to remove an adapter module from the NI-7932R.

1. Disconnect all cables to the adapter module.
2. Power off the NI-7932R.<sup>[1]</sup>
3. Unscrew the adapter module.
4. Remove the adapter module.

<sup>1</sup> If you cannot power down the NI-7932R, use the System Configuration application programming interface (API) to disable power to the adapter module.

## Troubleshooting the NI-7932R

### Related tasks

- Connecting the NI-7932R to the Host Computer

## Why Can't the NI-7932R Communicate with the Network?

1. Connect cables from your device to the host computer.
  1. If you are using the USB port, use a USB cable to connect the NI-7932R USB device port to a host computer.  
The USB driver creates a virtual network interface and assigns an IP address to the NI-7932R in the format of 172.22.11.x.
  2. If you are using the ethernet port, use an ethernet to connect the ethernet port to the host computer.
2. In MAX, expand your system under Remote Systems.
3. Select the Network Settings tab to configure the IP and other network settings.
4. (Optional) Use the RJ-45 Ethernet port 1 to reconnect the NI-7932R to the host computer. The NI-7932R attempts to initiate a DHCP network connection at powerup.  
If the NI-7932R cannot contain an IP address, it connects to the network with a link-local IP address with the form 169.254.x.x. The host computer communicates with the NI-7932R over a standard Ethernet connection.

## Why Doesn't the Device Appear in MAX?

If you cannot find the NI-7932R in MAX, complete the following steps.

- Ensure you have the correct version of FlexRIO Support installed on the host computer.
- Check the USB cable connections at the NI-7932R and host computer. Check the Ethernet cable connections at the host computer and router.
- If you have network firewalls or other security software enabled, try temporarily turning them off. You may also need to add an exception for MAX. In Windows 7, select Start » Control Panel » System and Security » Windows



Firewall » Allow a program through Windows Firewall. Click Allow another program, select Measurement & Automation, click Add, then click OK.

- Ensure that UDP port 44525 is open to communication on the host computer. If you are using an intelligent switch on the network, ensure that it is not disabling UDP port 44525.
- Hold down the RESET button for 5 seconds to reboot the target into safe mode. This prevents a real-time app from running. Sometimes a malfunctioning real-time app prevents network communication.
- Check the Device Manager to ensure the National Instruments USBLAN adapter is recognized. In Windows 7, select Start » Control Panel » Device Manager » Network adapters » National Instruments » USBLAN adapter. If the USBLAN adapter is not recognized, you must reinstall FlexRIO Support.
- Ensure that the Ethernet cable is connected correctly.


#### Related tasks

- [Configuring the System in Measurement & Automation Explorer \(MAX\)](#)

#### NI-7932R Front Panel

The following figure shows the NI-7932R front panel connectors, buttons, and LEDs.

Figure 3. NI-7932R



1. TRIG
2. REF CLK
3. Storage (μSD card)
4. USB device port
5. USB host
6. 1 Gigabit Ethernet
7. LED indicators
8. Reset
9. DC power source
10. FlexRIO adapter module connector
11. Port 0/Port 1 (SFP+ connectors)


#### Related information

- <http://www.ni.com/manuals/>

#### LED Indicators

The following figure shows the NI-7932R LEDs in more detail.

Figure 4. NI-7932R LEDs



### NI-7932R Module Signals

The following figure shows the available signals on the NI-7932R.

PCB Secondary Side		PCB Primary Side	
+3.3V	P1	P1	+3.3V
SDA	S74	S148	SCL
TB_Power_Good	S73	S147	TB_Present
+12V	P2	P2	+12V
Vcco	S72	S146	Vcco
Veeprom	S71	S145	RSVD
GND	G37	G37	GND
TDC_Assert_CLK_n	S70	S144	IOModSyncClk_n
TDC_Assert_CLK	S69	S143	IOModSyncClk
GND	G36	G36	GND
GPIO_24_n	S68	S142	GPIO_0_n
GPIO_24	S67	S141	GPIO_0
GND	G35	G35	GND
GPIO_25_n	S66	S140	GPIO_1_n
GPIO_25	S65	S139	GPIO_1
GND	G34	G34	GND
GPIO_CC_26_n	S64	S138	GPIO_CC_2_n
GPIO_CC_26	S63	S137	GPIO_CC_2
GND	G33	G33	GND
GPIO_27_n	S62	S136	GPIO_3_n
GPIO_27	S61	S135	GPIO_3
GND	G32	G32	GND
GPIO_28_n	S60	S134	GPIO_4_n
GPIO_28	S59	S133	GPIO_4
GND	G31	G31	GND
GPIO_29_n	S58	S132	GPIO_5_n
GPIO_29	S57	S131	GPIO_5
GND	G30	G30	GND
GPIO_30_n	S56	S130	GPIO_6_n
GPIO_30	S55	S129	GPIO_6
GND	G29	G29	GND
GPIO_31_n	S54	S128	GPIO_7_n
GPIO_31	S53	S127	GPIO_7
GND	G28	G28	GND
GPIO_32_n	S52	S126	GPIO_8_n
GPIO_32	S51	S125	GPIO_8
GND	G27	G27	GND
GPIO_33_n	S50	S124	GPIO_9_n
GPIO_33	S49	S123	GPIO_9
GND	G26	G26	GND
GPIO_34_n	S48	S122	GPIO_10_n
GPIO_34	S47	S121	GPIO_10
GND	G25	G25	GND
GPIO_35_n	S46	S120	GPIO_11_n
GPIO_35	S45	S119	GPIO_11
GND	G24	G24	GND
GPIO_36_n	S44	S118	GPIO_12_n
GPIO_36	S43	S117	GPIO_12
GND	G23	G23	GND
GPIO_37_n	S42	S116	GPIO_13_n
GPIO_37	S41	S115	GPIO_13
GND	G22	G22	GND

PCB Secondary Side		PCB Primary Side	
GND	G21	G21	GND
GPIO_CC_38_n	S40	S114	GPIO_CC_14_n
GPIO_CC_38	S39	S113	GPIO_CC_14
GND	G20	G20	GND
GPIO_39_n	S38	S112	GPIO_15_n
GPIO_39	S37	S111	GPIO_15
GND	G19	G19	GND
GPIO_40_n	S36	S110	GPIO_16_n
GPIO_40	S35	S109	GPIO_16
GND	G18	G18	GND
GPIO_41_n	S34	S108	GPIO_17_n
GPIO_41	S33	S107	GPIO_17
GND	G17	G17	GND
GPIO_42_n	S32	S106	GPIO_18_n
GPIO_42	S31	S105	GPIO_18
GND	G16	G16	GND
GPIO_43_n	S30	S104	GPIO_19_n
GPIO_43	S29	S103	GPIO_19
GND	G15	G15	GND
GPIO_44_n	S28	S102	GPIO_20_n
GPIO_44	S27	S101	GPIO_20
GND	G14	G14	GND
GPIO_45_n	S26	S100	GPIO_21_n
GPIO_45	S25	S99	GPIO_21
GND	G13	G13	GND
GPIO_46_n	S24	S98	GPIO_22_n
GPIO_46	S23	S97	GPIO_22
GND	G12	G12	GND
GPIO_47_n	S22	S96	GPIO_23_n
GPIO_47	S21	S95	GPIO_23
GND	G11	G11	GND
GPIO_48_n	S20	S94	GPIO_24_n
GPIO_48	S19	S93	GPIO_24
GND	G10	G10	GND
GPIO_49_n	S18	S92	GPIO_25_n
GPIO_49	S17	S91	GPIO_25
GND	G9	G9	GND
GPIO_CC_50_n	S16	S90	GPIO_CC_60_n
GPIO_CC_50	S15	S89	GPIO_CC_60
GND	G8	G8	GND
GPIO_51_n	S14	S88	GPIO_61_n
GPIO_51	S13	S87	GPIO_61
GND	G7	G7	GND
GPIO_52_n	S12	S86	GPIO_62_n
GPIO_52	S11	S85	GPIO_62
GND	G6	G6	GND
GPIO_53_n	S10	S84	GPIO_63_n
GPIO_53	S9	S83	GPIO_63
GND	G5	G5	GND
GPIO_54_n	S8	S82	GPIO_64_n
GPIO_54	S7	S81	GPIO_64
GND	G4	G4	GND
GPIO_55_n	S6	S80	GPIO_65_n
GPIO_55	S5	S79	GPIO_65
GND	G3	G3	GND
GPIO_56_n	S4	S78	GPIO_66_n
GPIO_56	S3	S77	GPIO_66
GND	G2	G2	GND
GPIO_57_n	S2	S76	GPIO_67_n
GPIO_57	S1	S75	GPIO_67
GND	G1	G1	GND

## Worldwide Support and Services

The National Instruments website is your complete resource for technical support. At [ni.com/support](https://ni.com/support), you have access to everything from troubleshooting and application development self-help resources to email and phone assistance from NI Application Engineers.

Visit [ni.com/services](https://ni.com/services) for NI Factory Installation Services, repairs, extended warranty, and other services.

Visit [ni.com/register](https://ni.com/register) to register your National Instruments product. Product registration facilitates technical support and ensures that you receive important information updates from NI.

A Declaration of Conformity (DoC) is our claim of compliance with the Council of the European Communities using the manufacturer's declaration of conformity. This system affords the user protection for electromagnetic compatibility (EMC) and product safety. You can obtain the DoC for your product by visiting [ni.com/certification](https://ni.com/certification). If your product supports calibration, you can obtain the calibration certificate for your product at [ni.com/calibration](https://ni.com/calibration).

National Instruments corporate headquarters is located at 11500 North Mopac Expressway, Austin, Texas, 78759-3504. National Instruments also has offices located around the world. For telephone support in the United States, create your service request at [ni.com/support](https://ni.com/support) or dial 1 866 ASK MYNI (275 6964). For telephone support outside the United States, visit the **Worldwide Offices** section of [ni.com/niglobal](https://ni.com/niglobal) to access the branch office websites, which provide up-to-date contact information, support phone numbers, email addresses, and current events.

## Where to Go Next

Refer to the following figure for information about other product tasks and associated resources for those tasks.

