


Identification

Type Designation	CT-Fuseholder-1	Series	CT
Description	Fuseholder Kit		

Technical Data

Max Rated Voltage	[V]	600
Max Rated Current	[A]	30
Wire Gauge	[AWG]	14

Connection Diagram



Installation Information

Install fuseholder on top by using 2x M4 and 2x 4mm serrated washers (included). Please take care not to cover the terminal identification.
 Connect F1 & F2 with primary and F3 with secondary side of the transformer.
 This kit is to be used with 50 – 1500VA CT-Transformers. Fuses are not included.

Variations may apply due to material's and production's tolerances. Objected to modifications without notice.