

PLCC Programming Adapter Farnell Order Code 797- 005

Function

The PLCC Programming Adapter is designed to enable 44 pin PLCC 16Cxx devices to be programmed in the PICSTART Plus.

Operation

Plug the Adapter into the PIC START Plus programmer ZIF socket and insert the PIC into the PLCC carrier. Hold down the Brown sprung loaded top on the PLCC socket and align the PIC. Gently press the PIC into the socket while releasing the Brown top. To remove the PIC after programming, press down the Brown top and catch the PIC as it's ejected from the socket.

