

There's so much more to Brainboxes

To enjoy the full benefits of Brainboxes, contact


UK - **t.** +44 (0)151 220 2500 **f.** +44 (0)151 252 0446
e. sales@brainboxes.com **w.** www.brainboxes.com
Brainboxes Ltd. Unit 3c Wavertree Boulevard South,
Wavertree Technology Park, Liverpool, L7 9PF, UK

USA - **t.** +1 (727) 538 7710
Brainboxes USA. 13575 58th Street North,
Suite 136, Clearwater, FL 33760-3746, USA.


Japan - **t.** +81-3-3833-2500
Brainboxes Japan. 1-2-8 Shinjyuku,
Shinjyuku-ku, Tokyo, 160-0022 Japan,

or visit **www.brainboxes.com**


ExpressCard 32 to 54mm Adaptor



Many laptops have the wider 54mm ExpressCard slot. By adding a 34mm to 54mm adaptor to your ExpressCard will eliminate movement in the slot ensuring reliable connectivity.



1. Extend the metal clip as shown on the picture above



2. Connect the metal clip to the left side of the ExpressCard. (The metal clip sits under the ExpressCard)
3. Now connect the plastic part to the other side of the ExpressCard.