(https://www.dfrobo t.com/product-1856.html)

## Introduction

The principle of the electric solenoid lock is the same as electromagnet, which means produce magnetism by electricity, the same sexes repel and opposites attract. Power on and unlock, power



off and lock. It adopts solid and durable latch hook, and the maximum stress is 735N (75kg). Pure copper electromagnetic valve coil, stable performance and temperature tolerance. It can provide a long usage life over 500 thousand times. Self-sprang design for objects from 0.5kg to 4kg and the sprang strength is adjustable. Feedback design, supporting remote status check. The lock equipped with emergency mechanic switch, supporting manual control, free from reserve power.

Compared with traditional electric solenoid locks in market, this product is designed to power off and unlock, which will help you save much power. And the mechanic lock avoids emergency of no power situations. Adjustable sprang power makes an easier control and a better space adaptability. Self-feedback design. It can be widely used in remote multi-locks and multi-cabinets projects.

#### Electric Solenoid Lock SKU: FIT0620-DFRobot

Particularly useful for small space and multi-cabinets projects. Such as smart cabinets, smart door locks, vending machines. It is also suitable for IOT(Internet of Things) low power consumption projects.

Please note that you'd better control the electrify time within 5 seconds when unlocking the lock. Long electrify time will damage the solenoid valve. The lock is unsuited to violence damage. Recommend to use it as an indoor lock or assistant lock.

## Features

- Responsive lock/unlock
- Adjustable self-spang
- Emegency mechanic lock
- Energy-saving design
- Support remote status monitor
- Convenient and small, especially suit to small space

# Specification

- Operation Voltage: 9V~12V DC
- Operating Current: 1.5A
- Stress Range: ≤735N(75kg)
- Lock Body Dimension: 73×58×13.3mm/2.87×2.28×0.52"
- Space between holes in lock body(Y/vertical): 36.5mm/1.43"
- Lock Latch Dimension: 34.5×20×28mm/1.36×0.79×1.10"
- Space between holes in lock latch: 25mm/0.98"

## **Dimension Diagram**





## Tutorial

### Preparation

### • Hardware

https://wiki.dfrobot.com/Electric Solenoid Lock SKU: FIT0620#target\_6

- DFRduino UNO x1
- Electric solenoid lock x1
- 12V Power adapter x1
- Digital relay module (Arduino compatible) x1
- Dupont wires x n
- Software
  - Arduino IDE (https://www.arduino.cc/en/Main/Software)

### **Connection Diagram**

Control the electric solenoid lock via a digital relay and 12V power adapter. Then the feedback wire will pass the lock status to the board DFRduino UNO.

| Num | Label       | Description                                         |
|-----|-------------|-----------------------------------------------------|
| 1   | Signal Wire | Signal ON/OFF                                       |
| 2   | GND         | _                                                   |
| 3   | VCC         | +                                                   |
| 4   |             | Ground the black wire, connect the green wire to D6 |



https://wiki.dfrobot.com/Electric Solenoid Lock SKU: FIT0620#target\_6





### Sample Code

Install Arduino IED software (http://arduino.cc/en/Main/Software), open its compiling environment and upload the following codes.

```
* @brief Electric Solenoid Lock
* @copyright [DFRobot](https://www.dfrobot.com), 2016
* @copyright
              GNU Lesser General Public License
* @author [Xiaoyu](Xiaoyu.zhang@dfrobot.com)
* @version V1.0
* @date 2019-03-11
* GNU Lesser General Public License.
* All above must be included in any redistribution
int Relay = 4;
void setup() {
 Serial.begin(57600);
 pinMode(6, INPUT PULLUP);
                       //Set Pin6 as output
 pinMode(Relay, OUTPUT);
}
void loop() {
 int singal=digitalRead(6);
 Serial.println(singal);
 digitalWrite(Relay, HIGH);
 delay(2000);
 digitalWrite(Relay, LOW);
 delay(2000);
}
```

### **Expected Results**

The electric solenoid lock is unlocking in every 4s. In Arduino serial monitor, the output is 0 when unlocked and 1 when locked.

# FAQ

For any questions, advice or cool ideas to share, please visit the **DFRobot Forum** (https://www.dfrobot.com/forum)

## **More Documents**