# OMRON

# **Built-in Amplifier Photoelectric Sensor**

### Water- and Oil-resistive Photoelectric Sensor with Metal Housing Ensuring Long Sensing Distance

- Satisfies the requirements of IP67, NEMA 6P, and IP67G (oil-tight).
- Sensing distance six times as long as OMRON's conventional Photoelectric Sensors ensures stable detection of objects.
- Ensures a vibration resistance of 10 Hz to 2 kHz and a shock resistance of 1,000 m/s<sup>2</sup> (approximately 100G).
- Incorporating an NPN and PNP output selector, thus reducing the stock of photoelectric sensors.
- Incorporating a fuzzy mutual interference prevention function.
- The E3S-C's optical axis coincides with its mechanical axis, thus ensuring axis adjustment with ease.



# \_\_\_\_\_

E3S-C

# Ordering Information -

## E3S-C

Connections	Appearance	Sensing method	Sensing distance	Operating mode	Model
Prewired	Horizontal	Through-beam	30 m	Light-ON	E3S-CT11
		Retroreflective	3 m (polarized red light source)	Dark-ON (selectable)	E3S-CR11
		Diffuse reflective	70 cm		E3S-CD11
			2 m		E3S-CD12
	Vertical	Through-beam	30 m		E3S-CT61
		Retroreflective	3 m (polarized red light source)		E3S-CR61
		Diffuse reflective	70 cm		E3S-CD61
			2 m		E3S-CD62
Junction connector	F	Through-beam	30 m	Light-ON	E3S-CT11-M1J
		Retroreflective	3 m (MSR polarized red light source)	Dark-ON (selectable)	E3S-CR11-M1J
		Diffuse reflective	70 cm		E3S-CD11-M1J
			2 m		E3S-CD12-M1J
	Vertical	Through-beam	30 m		E3S-CT61-M1J
		Retroreflective	3 m (MSR polarized red light source)		E3S-CR61-M1J
		Diffuse reflective	70 cm		E3S-CD61-M1J
			2 m		E3S-CD62-M1J

# Accessories (Order Separately)

#### For E3S-C

Name	Model	Remarks
Slit for Through-beam Sensor	E39-S61	A set consisting of a 0.5-mm, 1-mm, 2-mm, and 4-mm slits.
Vertical Mounting Bracket for the E3S42 or E3S44 for adjustment of the Photoelectric Sensor's optical axis direction (see note)	E39-L85	Replaces the E3S with the E3S-C Series.
Vertical Mounting Bracket for the E3S-DDD43 for adjustment of the Photoelectric Sensor's optical axis direction (see note)	E39-L86	
Special Mounting Bracket	E39-L87	

Note: Refer to page 17 for the optical axis direction of each model.

#### I/O Connector

Appearance		Cord	Model
Single-mold Connector on one end only	2 m	3-wired	XS2F-D421-DC0-A
	5 m	3-wired	XS2F-D421-GC0-A
Single-mold Connector on each end	2 m	4-wired	XS2W-D421-D81-A
	5 m	4-wired	XS2W-D421-G81-A
Connector Junction Box	5 m	4-point input (NPN)	XW3A-P445-G11
A a a		4-point input (PNP)	XW3A-P443-G11

# Specifications \_\_\_\_\_

## **Prewired Models**

Item	Through-beam	Retroreflective	Diffuse r	eflective		
	E3S-CT11 E3S-CT61	E3S-CR11 E3S-CR61	E3S-CD11 E3S-CD61	E3S-CD12 E3S-CD62		
LED for emitter	Infrared LED (880 nm)	Red LED (700 nm)	Infrared LED (880 nm)			
Sensitivity adjustment	One-turn adjustor		Two-turn endless adjustor	with an indicator		
Connection method	Prewired		·			
Weight	Horizontal model: 110 g (wit Vertical model: 115 g (wit	h 2-mm cord) h 2-mm cord)				
Output configuration	NPN or PNP (selectable) op	NPN or PNP (selectable) open collector current output				
Control output	Light ON or Dark ON (select	Light ON or Dark ON (selectable)				
Circuit protection	Load short-circuit protection (except for through-beam m		ection, and mutual interferen	nce prevention function		
Indicator	Emitter: Stability indicator (green), light indicator (red) Receiver: Stability indicator (green), light indicator (red)					
Materials	Case: Zinc die-cast   Operation panel: Sulfonated polyether   Lens: Acrylic   Mounting bracket: Stainless					
Attachments	Mounting bracket, screw driv (E39-R1: retroreflective mod		agonal bolts, instruction she	eet, and reflector		

### **Junction Connector Models**

Item	Through-beam	Retroreflective	Diffuse re	eflective	
	E3S-CT11-M1J E3S-CT61-M1J	E3S-CR11-M1J E3S-CR61-M1J	E3S-CD11-M1J E3S-CD61-M1J	E3S-CD12-M1J E3S-CD62-M1J	
LED for emitter	Infrared LED (880 nm)	Infrared LED (880 nm) Red LED (700 nm) Infrared LED (880 nm)			
Sensitivity adjustment	One-turn adjustor		Two-turn endless adjustor	with an indicator	
Connection method	M12 metal junction connector	or (cord length: 30 cm)			
Weight	Approx. 80 g (with 30-cm co	rd and connector)			
Output configuration	NPN or PNP (selectable) op	en collector current output			
Control output	Light ON or Dark ON (selectable)				
Circuit protection	Load short-circuit protection, reversed connection protection, and mutual interference prevention function (except for through-beam models)				
Indicator	Emitter: Emission indicator (red) Receiver: Stability indicator (green), light indicator (red)	Stability indicator (green), light indicator (red)			
Materials	Case: Zinc die-cast   Operation panel: Sulfonated polyether   Lens: Acrylic   Mounting bracket: Stainless				
Attachments	Mounting bracket, screw driv (E39-R1: retroreflective mod		agonal bolts, instruction she	et, and reflector	

-

## Ratings/Characteristics

Item	Through-beam	Retroreflective	Diffu	se reflective
	E3S-CT11(-M1J) E3S-CT61(-M1J)	E3S-CR11(-M1J) E3S-CR61(-M1J)	E3S-CD11(-M1J) E3S-CD61(-M1J)	E3S-CD12(-M1J) E3S-CD62(-M1J)
Power supply voltage	10 to 30 VDC (including right	ople (p–p) 10%)		
Current consumption	50 mA max. (emitter and receiver)	40 mA max.		
Sensing distance (white paper)	0 to 30 m	0 to 3 m	0 to 70 cm	0 to 2 m
Standard sensing object		With the E39-R1	30 x 30 cm (white pape	er)
Directional angle	$3^{\circ}$ to $15^{\circ}$	Sensor: 3° to 10° Reflector: 30° min.		
Variation in sensing distance			±10% max.	
Hysteresis			20% max. of sensing c	listance
Sensing distance with attachment	4-mm slit: 15 m 2-mm slit: 7 m 1-mm slit: 3.5 m 0.5-mm slit: 1.8 m	E39-R2: 0 to 4 m E39-R3: 0 to 150 cm E39-R4: 0 to 75 cm E39-RSA: 5 to 35 cm E39-RSB: 5 to 60 cm		
Min. sensing object (see note)	4-mm slit: 2.6-mm dia. 2-mm slit: 2-mm dia. 1-mm slit: 1-mm dia. 0.5-mm slit: 0.5-mm dia.	E39-R1 Reflector: 13-mm dia. E39-R3: 8-mm dia. E39-R4: 4-mm dia.		
Difference in direction between optical axis and mounting direction	±2° max. (checked along e mounting direction)	extended line in the	±2° max.	
Response time	1 ms max. for both operati	on and release		2 ms max. for both operation and release
Control output	30 VDC, 100 mA max. (res (NPN/PNP output selectab		1.2 V max., PNP output	: 2.0 V max.), open collector
Ambient illumination		nation on optical spot: 5,00 nation on optical spot: 10,0		
Ambient temperature	Operating: -25°C to 55°C	(with no icing)		
Ambient humidity	Operating: 35% to 85%			
Insulation resistance	20 MΩ min. (at 500 VDC)			
Dielectric strength	1,000 VAC, 50/60 Hz for 1			
Vibration resistance	Z directions			30G) 0.5 hrs each in X, Y, and
Shock resistance	Destruction: 1,000 m/s <sup>2</sup> (a	pprox. 100G) 3 times each	in X, Y, and Z directions	
Enclosure ratings	IEC: IP67, NEMA*: 6P (inc	doors only), JEM**: IP67G		

\*NEMA: National Electrical Manufactures Association \*\*JEM: Japan Electrical Manufacturers


Note: At the rated sensing distance, set a sensing object at half the rated sensing distance.


**Operating Range (Typical)** 


E3S-CD 1 (Left and Right)


# Engineering Data

#### Parallel Operating Range (Typical) E3S-CT□1











E3S-CD 1 (Up and Down)







#### Sensing Distance vs. **Object Size (Typical)** E3S-CD

20×20

30×30

1.2

1.1

0.9


0.8

0.7


0.6

0 5×5 10×10

Sensing distance (m)




#### **Reflector Parallel Movement (Typical)** E3S-CR 1




### Excess Gain vs. Set Distance (Typical)


#### E3S-CT 1







# Nomenclature



#### **Operation Panel**

Use the NPN and PNP output selector on the operation panel to select the type of output transistor. Use the Light ON and Dark ON selector on the operation panel to select the operation mode of the E3S-C.

# Operation -

# Output Circuits

## Prewired Models


Output configuration	Mode switch	Output transistor	Output circuits
NPN	Light ON	On when light is received.	Light indicator (Red) (Green) PNP output PNP output transistor NPN and PNP Brown 10 to 30 VDC Load Load Current Black Control
	Dark ON	ON when light is not received.	Set the NPN output selector in the Nami outp
PNP	Light ON	On when light is received.	Light indicator Stability (Red) PNP output (Red) Photoelectric NPN and PNP Black Control
	Dark ON	ON when light is not received.	Sensor main circuit VPN output selector Sēt the NPN and PNP Load current transistor ZD : Vz = 39 V

#### **Junction Connector Models**


Output configuration	Mode switch	Output transistor	Output circuits
NPN	Light ON	On when light is received.	Reflective Type and Receiver Light Stability indicator (Red) Green Photo- (Red) Green Photo- indicator NPN and PNP [ 0 10 to 30 VDC Usersor Control output transistor NPN and PNP [ 0 10 to 30 VDC Load Load Current output selector (See Control output transistor 0 V
	Dark ON	ON when light is not received.	ZD: Vz = 39 V Note: Set the NPN and PNP output selector to NPN. Emitter
PNP	Light ON	On when light is received.	Reflective Type and Receiver     Light   Stability   ① 10 to 30 VDC     indicator   PNP output transistor   ZD     (Red)   Creen)   Photo-output transistor     VPN and PNP   ①   Control output current transistor     Vz = 39 V   Note:   Set the NPN and PNP output transistor
	Dark ON	ON when light is not received.	Emitter Connector Pin Arrangement indicator indicat

#### I/O Connector Plug

NPN Output



PNP Output



	NPN output			PNP output			
Туре	Conductor	Connector pin	Application	Туре	Conductor	Connector pin	Application
DC	Brown	1	Power supply (+V)	DC	Brown	1	Power supply (+V)
	Black	4	Output		Black	4	Output
	Blue	3	Power supply (0 V)		Blue	3	Power supply (0 V)

# Timing Chart

## Prewired

Output configuration	Mode switch	Output transistor	Timing chart
NPN	Light ON	On when light is received.	Light received Light not received Light indicator ON (Red) OFF Output ON transistor OFF Load Operate (relay) Release (Between brown and black)
	Dark ON	ON when light is not received.	Light received Light not received Light indicator ON (Red) OFF Output ON transistor OFF Load Operate (Between brown and black)
PNP	Light ON	On when light is received.	Light received Light not received Light indicator ON (Red) OFF Output ON transistor OFF Load Operate (relay) Release (Between blue and black)
	Dark ON	ON when light is not received.	Light received Light not received Light indicator ON (Red) OFF Output ON transistor OFF Load Operate (relay) Release (Between blue and black)

#### Fuzzy Mutual Interference Prevention Function

If reflective Photoelectric Sensors are installed side by side, each reflective Photoelectric Sensor may be influenced by the light emitted from the other Photoelectric Sensors.


The fuzzy mutual interference prevention function of the E3S-C enables the E3S-C to monitor any light interference for a certain period before the E3S-C starts emitting light so that the E3S-C can retrieve the intensity and frequency of the light interference as data. Using this data, the E3S-C estimates with fuzzy inference the risk of the malfunctioning of the E3S-C and controls the timing of the E3S-C's light emission. When the risk is low:

The E3S-C waits until there is no light interference and emits light.



When the risk is high:

The E3S-C emits light between each light interference moment.



### Sensitivity Adjustment (Reflective Sensors)

Item	Position A	Position B	Setting
Sensing condition	Photoelectric sensor	Photoelectric sensor	
Sensitivity adjustor	Min. Max.	Min. Max.	Min. Max.
Indicators	OFF ON LIGHT (red)	OFF OFF LIGHT (green) OFF (red)	OFF STABILITY ON LIGHT (green) OK (red)
Procedure	Locate a sensing object at the sensing distance, set the sensitivity adjustor to the minimum scale position, and gradually increase sensitivity by turning the sensitivity adjustor clockwise until the incident light indicator (red LED) is ON. Position A is where the indicator has turned ON. Regard the maximum scale position as Position A if the indicator does not turned ON at full sensitivity.	Remove the sensing object and turn the sensitivity adjustor clockwise until the E3S-C detects the background object and the incident light indicator (red LED) is lit. The moment the red light indicator is lit, stop turning the sensitivity adjustor, the position of which is point B. Turn the sensitivity adjustor counterclockwise to decrease the sensitivity until the red light indicator is OFF. The moment the red light indicator is OFF, stop turning the sensitivity adjustor, the position of which is point C. If there is no background object, point C is where the sensitivity adjustor is set to maximum.	Set the sensitivity indicator to the position between Positions A and C (in some cases, Positions A and C are opposite of the above example). The photoelectric sensor will then work normally if the stability indicator (green) is lit with and without the sensing object. If it is not lit, stable operation cannot be expected, in which case a different sensing method must be applied.


Unlike conventional photoelectric sensors, the variation in the sensitivity of E3S photoelectric sensors is minimal. This means the sensitivity can be adjusted on only a single photoelectric sensor, and then the adjustors on the other photoelectric sensors can be set to the same scale position. There is no need to adjust the sensitivity of each photoelectric sensor individually.


# Dimensions ·

Note: All units are in millimeters unless otherwise indicated.


### E3S-C


#### E3S-CT11 (Receiver)






#### E3S-CT61 (Receiver)





- 2. The emitter for through-beam sensors have only the power supply indicator.
  - 3. The cord for emitters for through-beam sensors is two-conductor, 4 dia. (27 x 12 dia.).
- 4. Position of optical axis for through-beam sensors.



Note: 1. The mounting bracket can be attached to side A.


- 2. The emitter for through-beam sensors have only the power supply indicator.
- 3. The cord for emitters for through-beam sensors is two-conductor, 4 dia. (27 x 12 dia.).
- 4. Position of optical axis for through-beam sensors.

#### Attachments

#### E39-R1 Retroreflector

(Retroreflective type, provided with the E3S-CR11(-M1J)/CR61(-M1J))






15.6


-9.8-


#### Accessories (Order Separately) For Replacing the E3S Series with the E3S-C Series

#### E39-L85 Special Mounting Bracket

(Vertical/E3S-DD-42/44 for adjustment of the Photoelectric Sensor's optical axis direction)








Sensing Face Direction of the E3S Series

### Through-beam






Emitt


0 0

Receiver

Retroreflective/Diffuse Reflective E3S-DS30E44 E3S-R2E44




E3S-DS30E42 E3S-R2E42




#### E39-L86 Special Mounting Bracket

(Vertical/E3S-DDD243 for adjustment of the Photoelectric Sensor's optical axis direction)









Sensing Face Direction of the E3S Series


Through-beam E3S-5E43




#### Retroreflective/Diffuse Reflective E3S-DS30E43 E3S-R2E43





#### E39-L87 Special Mounting Bracket




E39-S61 Slit for E3S-C











# Installation

#### Connections Load (Relay)



**Note:** If the load is a relay, insert a surge absorbing diode between the coils of the relay. The connection examples are for sensors with the NPN output.

#### With Sensor Controller (S3D2)



# Precautions

#### Connection

If the input/output lines of the photoelectric sensor are placed in the same conduit or duct as power lines or high-voltage lines, the photoelectric sensor could be induced to malfunction, or even be damaged, by electrical noise. Either separate the wiring, or use shielded lines as input/output lines to the photoelectric sensor.

The cord connected to the E3S-C can be extended up to 100 m provided that the diameter of each wire of the cord is  $0.3 \text{ mm}^2$  minimum.

#### **Startup Operation**

A maximum of 100 ms is required from the time power is turned on until the E3S-C is able to detect objects. If power is supplied to the loads and the E3S-C from different sources, turn on power to the E3S-C first.

#### **Power Supply**

If a standard switching regulator is used as a power supply, the frame ground (FG) terminal and the ground (G) terminal must be grounded, or otherwise the E3S-C may malfunction, due to the switching noise of the power supply.

#### Water Resistivity

Do not use the E3S-C in water, in the rain, or outdoors.

To ensure the water resistivity of the E3S-C, tighten the screws of the operation panel cover to a torque of 3.5 to 5.5 kgf  $\cdot$  cm (0.34 N  $\cdot$  m to 0.54 N  $\cdot$  m).

#### Oil and Chemical Resistivity

Do not use the E3S-C in oils or liquid chemicals.

Although the E3S-C is oil-resistive, refer to the following table before using the E3S-C in places where oil may be sprayed on the E3S-C.

Tests were carried out with the following oils and it was certified that the E3S-C resists these oils.

Oil	JIS classification	Product name	Kinematic viscosity (mm <sup>2</sup> /s (cst)) at 40°C	PH
Lubricating oil		Velocite No.3	2.02	
Water insoluble machining oil	No. 5, type 2	Daphnecut	10 min. and less than 50	
	No. 11, type 2	Yushiron Oil No. 2 ac	Less than 10	
Water soluble machining oil	No. 1, type W1	Yushiroken EC50T-3		7 to 9.5
		Yushiron Lubic HWC68		7 to 9.9
	No. 2, type W1	Griton 1700D		7 to 9.2
	No. 1, type W2	Yushiroken S50N		7 to 9.8

Note: 1. The E3S-C maintained a minimum insulation resistance of 100 MΩ after the E3S-C was dipped in all the above oils at a temperature of 50°C for 240 hours.

2. When using the E3S-C in a place where an oil other than the ones listed above is sprayed on the E3S-C, refer to the above kinematic viscosity and ph values. The location may be suitable for the E3S-C if the kinematic viscosity and pH values of the oil are close to the above kinematic viscosity and pH values, but make sure that the oil does not contain any additive that may have a negative influence on the E3S-C.

3. JIS: Japan Industrial Standards

#### Cable

The E3S-C uses an oil-resistive cord to ensure oil resistivity. Do not allow the cable to be repeatedly bent during application.

Do not allow the cable to be bent to a radius of less than 25 mm.

Mounting

When mounting the E3S-C, do not hit the E3S-C with a hammer, or the E3S-C will loose watertightness.

Use M4 screws to mount the E3S-C.

The tightening torque of each screw must be 12 kgf  $\bullet$  m (1.18 N  $\bullet$  m) maximum.


#### **Mounting Bracket**


When mounting the E3S-C with the mounting bracket so that sensing objects will be in the direction of the mechanical axis, use the optical axis lock holes.

If it is not possible to mount the E3S-C so that the sensing objects will be in the direction the mechanical axis, move the E3S-C upwards, downwards, to the left, or to the right and secure the E3S-C in the center of the range where the light indicator will be lit, at which time make sure that the stability indicator is lit.

#### Direct Mounting

Mount the E3S-C as shown in the following illustration.





#### Malfunctioning


If an inverter motor or servomotor is used with the E3S-C, the frame ground (FG) terminal and the ground (G) terminal must be grounded, or otherwise the E3S-C may malfunction.

#### **Optical Axis Adjustment**

Direct the mounting axis of the mounting bracket in the direction where sensing objects will be located. The optical axis of the E3S-C coincides with the mounting axis of the mounting bracket, which enables the user to adjust the optical axis of the E3S-C with ease.


#### **Optical Lock Holes**

By tightening the optical axis lock holes with screws, the mounting bracket will be in the direction of the optical axis of the E3S-C.



#### **Optical Axis of Through-bean Sensor**

The E3S-C through-beam models incorporates two lenses, one of which will be used as shown in the following illustration. When using a slit, the slit must be on the side where the lens to be used is located.



### ■ Replacing the E3S with the E3S-C

The following is the conversion table for changing from the E3S to the E3S-C.

Models

Conventional models	New models
E3S-5E4/5B4	E3S-CT11
E3S-5E41/5B41	E3S-CT61
E3S-R2E4/R2B4	E3S-CR11
E3S-R2E41/R2B41	E3S-CR61
E3S-DS30E4/DS30B4	E3S-CD11
E3S-DS30E41/DS30B41	E3S-CD61

#### Comparison

Item	E3S	E3S-C
Sensing distance	Through-beam: 5 m Retroreflective: 2 m (polarized) Diffuse reflective: 30 cm (infrared type)	Through-beam: 30 m Retroreflective: 3 m (polarized) Diffuse reflective: 70 cm/2 m (infrared type)
Response time	Through-beam: 3 ms max. Retroreflective/Diffuse reflective: 1 ms max.	1 ms max. (2 ms for 2-m diffusive models)
Enclosure rating	IP67 (with steel mounting bracket)	IP67, NEMA 6P, and IP67G (with stainless mounting bracket)
Vertical operation panel (sensitivity adjustor) (see note 1)	The sensitivity adjustor and indicator are on the face where the lens is located.	The sensitivity adjustor and indicator are on the top panel.
Outputs (see note 2)	Voltage and current	Open collector
Power supply voltage	12 to 24 VDC ±10%	10 to 30 VDC
LED for emitter	Infrared	Infrared (red for retroreflective models)
Variation in sensing distance	Not specified (approx. 150% max.)	30% max.
Difference in direction between optical axis and mounting direction	Not specified (approx. 12° max.)	±2°max.
Dark ON and light ON selection (see note 1)	Selected with the connection of power supply cord	Selector
Dimensions (see note 1)	Through-beam: 23 x 20 x 55 mm Diffuse reflective: 23 x 20 x 55 mm	Horizontal: 23 x 20 x 50 mm Vertical: 57 x 20 x 23 mm
Dimensions with mounting bracket attached (see note 1)	Through-beam/Retroreflective/Diffuse reflective: Horizontal: 55 x 40.2 x 32 mm Vertical: 63 x 40.2 x 32 mm	Through-beam/Retroreflective/Diffuse reflective: Horizontal: 52.6 x 40.2 x 29.5 mm Vertical: 60.6 x 40.2 x 32.2 mm
Mounting bracket	Iron	Stainless steel
Material (lens)	Polycarbonate	Acrylic

Note: 1. Especially take these items into consideration when replacing E3S models with E3S-C models.

 When connecting the E3S-C to a timer or counter with voltage input, be sure to connect a 4.7-kΩ resistor between the output and power supply lines. When the E3S-C is turned ON, a pulse signal may be output from the sensor.

ALL DIMENSIONS SHOWN ARE IN MILLIMETERS.

To convert millimeters into inches, multiply by 0.03937. To convert grams into ounces, multiply by 0.03527.

#### Cat. No. E229-E1-3 In the interest of product improvement, specifications are subject to change without notice.

# **OMRON** Corporation

Systems Components Division H.Q. 28th Fl., Crystal Tower Bldg. 1-2-27, Shiromi, Chuo-ku, Osaka 540 Japan Phone: 06-949-6012 Fax: 06-949-6021

Printed in Japan 0397-1M (0194) a