

Specifications

- Suitable detector types : Most models & makes of detector
- Maximum height : Up to 30ft / 9m using Solo extension poles
- Operating features : Swing frame for difficult to access detectors
- Environment : **Operating temperature: 5°C to 45°C / 40°F to 115°F**
: **Storage Temperature: -10°C to 50°C / 15°F to 120°F**
: Humidity: 0-85% RH non-condensing

Maintenance Notes:

- ◆ Clean with warm soapy water and a soft, lint-free cloth.
- ◆ Recommended for use with Solo Aerosol

Other Products Available from your Supplier

- **SOLO 719419** Telescopic pole, extendable, non conductive for accessing detectors at height to 6m (20ft). Compatible with all other SOLO tools
- **SOLO 719420** Extension pole, non-conductive rigid pole section. For use on its own or to extend SOLO 719419. Max of 3 recommended to reach up to 9m/30ft
- **SOLO 719407** Universal detector removal / replacement tool
- **SOLO™ 424** 230-240v Heat Detector Tester
- **SOLO™ 423** 110-120v Heat Detector Tester
- **SOLO 461** Cordless CAT Heat Detector Tester
- **SOLO 610** Protective Carrying and Storage Bag
- **SOLO 719444** Aerosols for use with SOLO dispenser



Solo 719377 is optimised for performance with Solo Aerosol.
Use of alternative aerosols will invalidate the guarantee.

Farnell Electronic Components
Canal Road
Armley
Leeds
West Yorks LS12 2TU



719377 Smoke Aerosol Dispenser



Brief Description

- Designed for smoke detector testing at varying heights
- Constructed from strong, durable, yet lightweight materials
- Can be used with either Solo Telescopic or Extension poles
- Robust design
- Light touch activation for use on false ceilings
- Can be used at any angle

Instructions for use for Solo 719377 Smoke Aerosol Dispenser

- ◆ Unscrew retainer cup and remove
- ◆ Place aerosol canister into bottom of retainer cup, nozzle upwards
- ◆ Replace retainer cup & screw upwards until aerosol canister is *just* activated by pressure
- ◆ Unscrew slightly to stop aerosol self-activation
- ◆ Insert the Solo 719377 product onto Solo Telescopic or Extension Pole
- ◆ Place Solo 719377 over detector, ensuring a seal
- ◆ Press upwards slightly to activate Solo 719377 with aerosol
- ◆ Press upwards slightly to activate Solo 719377 with aerosol
- ◆

Specifications

Suitable detector types	: Most models & makes of detector
Maximum height	: Up to 30ft / 9m using Solo extension poles
Operating features	: Swing frame for difficult to access detectors
Environment	: Operating temperature: 5°C to 45°C / 40°F to 115°F : Storage Temperature: -10°C to 50°C / 15°F to 120°F : Humidity: 0-85% RH non-condensing

Maintenance Notes:

- ◆ Clean with warm soapy water and a soft, lint-free cloth.
- ◆ Recommended for use with Solo Aerosol

Other Products Available from your Supplier

- **SOLO 719419** Telescopic pole, extendable, non conductive for accessing detectors at height to 6m (20ft). Compatible with all other SOLO tools
- **SOLO 719420** Extension pole, non-conductive rigid pole section. For use on its own or to extend SOLO 719419. Max of 3 recommended to reach up to 9m/30ft
- **SOLO 719407** Universal detector removal / replacement tool
- **SOLO™ 424** 230-240v Heat Detector Tester
- **SOLO™ 423** 110-120v Heat Detector Tester
- **SOLO 461** Cordless CAT Heat Detector Tester
- **SOLO 610** Protective Carrying and Storage Bag
- **SOLO 719444** Aerosols for use with SOLO dispenser



Solo 719377 is optimised for performance with Solo Aerosol.
Use of alternative aerosols will invalidate the guarantee.

Farnell Electronic Components
Canal Road
Armley
Leeds
West Yorks LS12 2TU



719377 Smoke Aerosol Dispenser



Brief Description

- Designed for smoke detector testing at varying heights
- Constructed from strong, durable, yet lightweight materials
- Can be used with either Solo Telescopic or Extension poles
- Robust design
- Light touch activation for use on false ceilings
- Can be used at any angle

Instructions for use for Solo 719377 Smoke Aerosol Dispenser

- ◆ Unscrew retainer cup and remove
- ◆ Place aerosol canister into bottom of retainer cup, nozzle upwards
- ◆ Replace retainer cup & screw upwards until aerosol canister is *just* activated by pressure
- ◆ Unscrew slightly to stop aerosol self-activation
- ◆ Insert the Solo 719377 product onto Solo Telescopic or Extension Pole
- ◆ Place Solo 719377 over detector, ensuring a seal
- ◆ Press upwards slightly to activate Solo 719377 with aerosol
- ◆ Press upwards slightly to activate Solo 719377 with aerosol