

Material	Finish
Brass	Nickel
Brass	Gold
PTFE	N/A
BE CU	Nickel
SI Rubber	Rubber
Brass	Nickel
PTFE	N/A
Brass	Nickel
Polyolefin	Black
	Brass Brass PTFE BE CU SI Rubber Brass PTFE Brass




## CONSMA012-R58 ASSEMBLY INSTRUCTIONS

- 1. Strip cable to recommended dimensions.
- 2. Slip heat shrink and crimp ring onto stripped cable.
- 2. Slide the cable into the body until the center conductor is centered in the fork.
- 3. Push the braided shield over the barrel.
- 4. Solder the center conductor into the center of the fork.
- 5. Slide the crimp ring over the shield and crimp with a 0.213" hex crimp tool (or one labeled for use with RG-58 cable).
- 6. Trim off any excess shield wire sticking out from the ring.
- 7. Slip the heat shrink over the crimp ring until it is against the body and shrink.
- 8. Insert insulator into body.
- 9. Push the cover into the opening.



REVISIONS **REV DESCRIPTION** DATE **APPV** Added new title block, heat shrink and instructions; В 2-JUL-12 SAH updated cover and insulator drawings



SIDE VIEW

WARNING: THIS DRAWING CONTAINS PROPRIETARY INFORMATION

Ø0.260

[6.60]

NOTES: (UNLESS OTHERWISE SPECIFIED)

- 1. ALL DIMENSIONS ARE IN INCHES [mm].
- 2. DIMENSIONS APPLY AFTER FINISHING.
- MANUFACTURE TO BE COMPLIANT WITH EU RoHS DIRECTIVE.
- 4. SAFETY BREAK ALL SHARP CORNERS AND EDGES .02 MAXIMUM.

THAT IS THE SOLE PROPERTY OF LINX TECHNOLOGIES, AND SHALL BE TREATED AS SUCH. NO DISCLOSURE OR REPRODUCTION OF THIS DOCUMENT IS PERMITTED, IN WHOLE OR IN PART, WITHOUT THE TITLE: EXPRESS WRITTEN PERMISSION OF LINX TECHNOLOGIES OR ITS SMA MALE RIGHT ANGLE DESIGNATED AGENTS. MATERIAL: TOLERANCES: PROJECTION: CABLE END CRIMP FOR RG58 CABLE .020 [0.50]-.200 [5.00]= ±.008 [0.20] .200 [5.00]-1.200 [30.00]= ±.016 [0.40] 4.75 [120.0]-4.75 [120.0]=±.024 [0.60] ANGLES: ±1° SIZE ANGLES: ±1° ANGLES: ±1 REV CONSMA012-R58 В FINISH: DRAWN: B.MURPHY DT: 2-JUL-12 **ENGR: S.HOGAN** SCALE: 2:1 DT: 2-JUL-12 DO NOT SCALE DRAWING SHEET 1 OF 1 LDCFDLT A