







# **Model Number**

## NCB10-30GM40-N0-V1

#### **Features**

- 10 mm flush
- Usable up to SIL 2 acc. to IEC 61508
- Stainless steel housing

# **Technical Data**

# General specifications Switching element function

Nominal ratings

Nominal voltage U<sub>o</sub> 8 V
Switching frequency f 0 ... 200 Hz
Hysteresis H 1 ... 15 typ. 5 %
Reverse polarity protection
Short-circuit protection yes

NAMUR, NC

Current consumption

Measuring plate not detected

Measuring plate detected ≤ 1 mA
Switching state indicator Multihole-LED, yellow

## Functional safety related parameters

 $\begin{array}{ll} \text{MTTF}_d & 1821 \, a \\ \text{Mission Time } (T_M) & 20 \, a \\ \text{Diagnostic Coverage (DC)} & 0 \, \% \end{array}$ 

#### Ambient conditions

# Mechanical specifications

Connection type Connector M12 x 1 , 4-pin
Housing material Stainless steel 1.4305 / AISI 303
Sensing face PBT

# Degree of protection General information

Use in the hazardous area see instruction manuals Category 1G; 2G; 3G; 1D; 3D

#### Compliance with standards and directives

### Standard conformity


NAMUR EN 60947-5-6:2000 IEC 60947-5-6:1999
Electromagnetic compatibility NE 21:2007
Standards EN 60947-5-2:2007 IEC 60947-5-2:2007

#### Approvals and certificates


UL approval cULus Listed, General Purpose CSA approval cCSAus Listed, General Purpose

CCC approval / marking not required for products rated ≤36 V

## **Dimensions**



# **Electrical Connection**



Wire colors in accordance with EN 60947-5-6

BN (brown) BU (blue)

FPEPPERL+FUCHS

2

#### Equipment protection level Ga

Instruction

Device category 1G EC-Type Examination Certificate CE marking

ATEX marking

Directive conformity Standards

Appropriate type

 $\begin{array}{ll} \text{Effective internal inductivity} & \quad C_i \\ \text{Effective internal inductance} & \quad L_i \\ \end{array}$ 

General

Ambient temperature

Installation, commissioning

Maintenance

### Special conditions

Protection from mechanical danger

Electrostatic charge

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2048  $\ensuremath{\mathrm{X}}$ 

**C**€0102

(x) II 1G Ex ia IIC T6...T1 Ga The Ex-related marking can also be printed on the enclosed label.

94/9/EG

EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions

NCB10-30GM...-N0...

 $\leq$  105 nF; a cable length of 10 m is considered.

 $\leq$  100  $\mu H$ ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions.

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permis-

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

Details of the correlation between the type of circuit connected, the maximum permissible ambient temperature, the temperature class, and the effective internal reactance values can be found on the EC-type examination certificate. **Note:** Use the temperature table for category 1!!! The 20 % reduction in accordance with EN 1127-1 has already been applied to the temperature table for category 1.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy the requirements of category ia.

Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. If the Exrelated marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The connecting parts of the sensor must be set up in such a way that degree of protection IP20, in accordance with IEC 60529, is achieved as a minimum.

When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure.

The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.

When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing parts. Avoid electrostatic charges that can cause electrostatic discharge when installing or operating the device. Information on electrostatic hazards can be found in the technical specification IEC/TS 60079-32-1. Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

#### **Equipment protection level Gb**

Instruction

#### Device category 2G

EC-Type Examination Certificate CE marking

ATEX marking

Directive conformity

Standards

Appropriate type

Effective internal inductivity  $C_{i}$ Effective internal inductance

Maximum permissible ambient temperature Tamb

Installation, commissioning

Maintenance

#### Special conditions

Protection from mechanical danger

Electrostatic charge

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2048 X €0102

(a) II 1G Ex ia IIC T6...T1 Ga
The Ex-significant identification is on the enclosed adhesive label

EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions

NCB10-30GM...-N0..

 $\leq$  105 nF; a cable length of 10 m is considered.

 $\leq$  100  $\mu$ H; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permis-

sible minimum ignition energies may have to be taken into consideration.

Details of the correlation between the type of circuit connected, the maximum permissible ambient temperature, the temperature class, and the effective internal reactance values can be found on the EC-type examination certificate

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The connecting parts of the sensor must be set up in such a way that degree of protection IP20, in accordance with IEC 60529, is achieved as a minimum.

When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

PEPPERL+FUCHS

## Equipment protection level Gc (nL)

Note

#### Instruction

#### Device category 3G (nL)

CE marking

ATEX marking

Directive conformity
Standard conformity

Effective internal capacitance  $C_i$ Effective internal inductance  $L_i$ 

General

Installation, commissioning

#### Maintenance

#### Special conditions

for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T4-T1 for Pi=242 mW, Ii=76 mA, T6 for Pi=242 mW, Ii=76 mA, T5 for Pi=242 mW, Ii=76 mA, T5

Protection from mechanical danger

Protection from UV light

Electrostatic charge

Connection parts

This instruction is only valid for products according to EN 60079-15:2005, valid until 01-May-2013

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

 $C \in$ 

(a) II 3G Ex nL IIC T6 X The Ex-significant identification is on the enclosed adhesive label

94/9/EG

EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions  $\leq$  105 nF; a cable length of 10 m is considered.

 $\leq$  100  $\mu H$ ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with an energy-limited circuit, which satisfies the requirements of IEC 60079-15. The explosion group complies with the connected, supplying, power limiting circuit. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

55 °C (131 °F) 52 °C (125.6 °F) 52 °C (125.6 °F) 52 °C (125.6 °F) 44 °C (111.2 °F) 44 °C (111.2 °F) 44 °C (111.2 °F)

The sensor must not be exposed to **ANY FORM** of mechanical danger. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

The sensor must be protected against harmful UV radiation. This can be achieved by using the sensor indoors.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

#### Equipment protection level Gc (ic)

Instruction

#### Device category 3G (ic)

Certificate of Compliance

CE marking

ATEX marking

Directive conformity

Standards

Effective internal inductivity Ci Effective internal inductance

General

Installation, commissioning

#### Maintenance

#### Special conditions

for Pi=34 mW li=25 mA T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW. Ii=25 mA. T5 for Pi=64 mW. Ii=25 mA. T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T4-T1 for Pi=242 mW, Ii=76 mA, T6 for Pi=242 mW, Ii=76 mA, T5 for Pi=242 mW. Ii=76 mA. T4-T1 Protection from mechanical danger

Electrostatic charge

Connection parts

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PF 13 CERT 2895 X

(€

EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection category "ic" Use is restricted to the following stated conditions

≤ 105 nF; a cable length of 10 m is considered.

 $\leq$  100  $\mu H$  ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11. The explosion group complies with the connected, supplying, power limiting circuit. If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immediate vicinity of the sensor! The background surface to which the adhesivelabel is to be applied must be clean and free from grease! The applied label must be durable and remain legible, with due consideration of the possibility of chemical corro-

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

55 °C (131 °F) 52 °C (125.6 °F) 52 °C (125.6 °F) 52 °C (125.6 °F) 44 °C (111.2 °F) 44 °C (111.2 °F) 44 °C (111.2 °F)

The sensor must not be mechanically damaged.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

#### **Equipment protection level Da**

Instruction

#### Device category 1D

EC-Type Examination Certificate

CE marking

ATEX marking

Directive conformity

Standards

Appropriate type

 $\begin{array}{ll} \text{Effective internal inductivity} & \quad C_i \\ \text{Effective internal inductance} & \quad L_i \end{array}$ 

General

Maximum permissible ambient temperature Tamb

Installation, commissioning

Maintenance

## Special conditions

Protection from mechanical danger

Electrostatic charge

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust

PTB 00 ATEX 2048 X

**C**€0102

⟨ II 1D Ex ia IIIC T135°C Da The Ex-related marking can also be printed on the enclosed label.

94/9/EG

EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions

NCB10-30GM...-N0...

 $\leq$  105 nF; a cable length of 10 m is considered.

 $\leq$  100  $\mu H$ ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed.

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions.

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permissions.

if the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

Details of the correlation between the type of circuit connected, the maximum permissible ambient temperature, the surface temperature, and the effective internal reactance values can be found on the EC-type-examination certificate.

The maximum permissible ambient temperature of the data sheet must be noted, in addition, the lower of the two values must be maintained.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

If the Ex-related marking is printed only on the supplied label, then this must be

If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The connecting parts of the sensor must be set up in such a way that degree of protection IP20, in accordance with IEC 60529, is achieved as a minimum.

When using the device in a temperature range of -60  $^{\circ}$ C to -20  $^{\circ}$ C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Avoid electrostatic charges that can cause electrostatic discharge when installing or operating the device. Information on electrostatic hazards can be found in the technical specification IEC/TS 60079-32-1. Do not attach the nameplate provided in areas where electrostatic charge can build up.

#### Equipment protection level Dc (tD)

Instruction

#### Manual electrical apparatus for hazardous areas

Device category 3D

for use in hazardous areas with non-conducting combustible dust CE marking

ATEX marking

⟨Ex⟩ II 3D Ex tD A22 IP67 T80°C X The Ex-significant identification is on the enclosed adhesive label

Directive conformity

94/9/EG EN 61241-0:2006, EN 61241-1:2004

Standards

Protection via housing "tD"
Use is restricted to the following stated conditions

Genera

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the equipment.

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Installation, commissioning The statutory requirements, directives and standards applicable to the intended use and application must be observed.

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possi-

bility of chemical corrosion

Maintenance

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Special conditions

Minimum series resistance Ry

A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance with the following list. This can also be assured by using a switch amplifier

Maximum operating voltage U<sub>Bmax</sub>

The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted

Maximum permissible ambient tempera-

Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.

ture  $T_{Umax}$ 

66 °C (150.8 °F)

at U\_Bmax=9 V, R\_V=562  $\Omega$ 

using an amplifier in accordance with 66 °C (150.8 °F)

EN 60947-5-6

Protection from mechanical danger

The sensor must not be exposed to ANY FORM of mechanical danger.

Protection from UV light

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas

Electrostatic charge

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Plug connector

The plug connector must not be withdrawn under voltage. The proximity switch is identified as follows: "WARNING - DO NOT SEPARATE WHEN ENERGIZED". With the plug connector disconnected, soiling of the internal area must be prevented. (i.e. the area that is inaccessible when the connector is inserted) The plug connection can only be separated using a tool. This is achieved by using the locking protection V1-Clip (Mounting accessory from Pepperl + Fuchs).

PEPPERL+FUCHS

#### Equipment protection level Dc (tc)

Instruction

## Device category 3D

Certificate of Compliance CE marking

ATEX marking

Directive conformity

Standards

General

Installation, commissioning

Maintenance

#### Special conditions

Minimum series resistance R<sub>V</sub>

Maximum operating voltage U<sub>Bmax</sub>

Maximum permissible ambient temperature T<sub>Umax</sub>

at  $U_{Bmax}$ =9 V,  $R_{V}$ =562  $\Omega$ 

using an amplifier in accordance with EN 60947-5-6

Protection from mechanical danger

Protection from UV light

Electrostatic charge

Plug connector

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust PF 15CERT3774  $\rm X$ 

(€

II 3D Ex tc IIIC T80°C Dc

The Ex-related marking can also be printed on the enclosed label.

94/9/EG

EN 60079-0:2012+A11:2013, EN 60079-31:2014

Protection by enclosure "tc" Some of the information in this instruction manual is more specific than the information provided in the datasheet.

The corresponding datasheets, declarations of conformity, EC-type examination certificates, certifications, and control drawings, where applicable (see datasheets), form an integral part of this document. These documents can be found at www.pepperl-fuchs.com. The maximum surface temperature of the device was determined without a layer of dust on the apparatus. Some of the information in this instruction manual is more specific than the information provided in the datasheet.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immediate vicinity of the sensor! The background surface to which the adhesivelabel is to be applied must be clean and free from grease! The applied label must be durable and remain legible, with due consideration of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance with the following list. This can also be assured by using a switch amplifier.

The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.

Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.

66 °C (150.8 °F)

66 °C (150.8 °F)

The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Avoid electrostatic charges that can cause electrostatic discharge when installing or operating the device. Information on electrostatic hazards can be found in the technical specification IEC/TS 60079-32-1. Do not attach the nameplate provided in areas where electrostatic charge can build up.

The plug connector must not be withdrawn under voltage. The proximity switch is identified as follows: "WARNING - DO NOT SEPARATE WHEN ENERGIZED". With the plug connector disconnected, soiling of the internal area must be prevented.(i.e. the area that is inaccessible when the connector is inserted)