


## SKU:DFR0052 (<https://www.dfrobot.com/product-399.html>)




(<https://www.dfrobot.com/product-399.html>)

## Introduction

The DFRobot Vibration Sensor (<https://www.dfrobot.com/product-399.html>) buffers a piezoelectric transducer that responds to strain changes by generating a measurable output voltage change. Therefore the voltage is proportional with the strength of vibration.


## Specification

- Power supply: Not necessary to power the module
- Interface: Analog
- Supply Voltage: 3.3V to 5V
- Current: less than 1mA
- Weight: 10g



## Tutorial

### Connection diagram




## Sample Code

```
void setup()
{
  Serial.begin(9600); //
}
void loop()
{
  int val;
  val=analogRead(0);//Connect the sensor to analog pin 0
  Serial.println(val,DEC);//
  delay(100);
}
```

## Result

When no pressure is applied to the piezoelectric ceramics, the analog output is 0; when pressure is applied to the piezoelectric ceramics, the analog output will be correlated to the amount of pressure.



## FAQ

---

For any questions/advice/cool ideas to share, please visit **DFRobot Forum** (<https://www.dfrobot.com/forum/>).